



OPERATIONS MANUAL – PWR05

UK

Dear Customer, Congratulations on the purchase of your loud-speaker(s). Please read these instructions carefully and keep them for future reference.



Rechargeable BT Speaker

Introduction:

Congratulations on your purchase of the PWR05 portable multi-function, engineered and manufactured by us. The PWR05 includes 1" X2 tweeter, 3" X2 mediant and 6" woofer that produces an even and smooth studio quality sound in a sound reinforcement speaker. Our design goal was to build a speaker with accurate playback, smooth dispersion of mid and high frequencies, and an ergonomic design for easy transport and setup. The result is a sound reinforcement system dynamic enough to use at home, in the studio, parties or in a home theater and outing use.

Features:

1. Steel basket woofer
2. Auxiliary line input
3. High Temperature Voice Coil
4. Stereo Sound output
5. Bluetooth Pairing
6. USB [Charging]
7. Built-in Rechargeable Battery (7.4V/6.6A)

Cautions:

1. All operating instructions should be read before using this equipment.
2. To reduce the risk of electric shock, do not open the unit. There are NO REPLACEABLE PARTS INSIDE. Please refer servicing to a qualified service technician.
3. Do not expose this unit to direct sunlight or to a heat source such as a radiator or stove.
4. This unit should be cleaned only with a damp cloth. Avoid solvents or other cleaning detergents.
5. When moving this equipment, it should be placed in its original carton and packaging. This will reduce the risk of damage during transit.
6. DO NOT EXPOSE THIS UNIT TO RAIN OR MOISTURE.
7. DO NOT USE ANY SPRAY CLEANER OR LUBRICANT ON ANY CONTROLS OR SWITCHES.
8. Make sure ALL of your equipment is completely OFF and lower ALL VOLUME, LEVEL & GAIN controls before connecting the speaker.
9. Rechargeable Battery Usage:
10. Please charge the battery timely when the power of the battery is used up.
11. After used, please charge the battery every three month.
12. If storage without charge for lone time, it may not be charge successfully anymore.

▲ Failing to adhere to the cautions above will void the manufacturer warranty!

Functions [fig 1]:

1. Press ►/||, to start/pause playback.
2. By pressing ◀◀, you will skip back to the previous track.
3. By pressing ▶▶, you will skip forward to the next track.
4. Press ④ to pair your external playback device with the PWR05, when you are pressing ④, a voice will say "Bluetooth on". After successful pairing, the voice will tell you "Bluetooth connected". NOTE: If you turn on your PWR05, the Bluetooth function will automatically be active and will pair with the last used playback device automatically (if the Bluetooth function of your playback device is on).
5. If you would like to link two PWR05, press 'TWS' on both devices. When you press this button, a voice will say "pairing", after the link has been successfully established, the voice will say "pairing successful". This procedure may take up to 15 seconds.
6. Press - or + to decrease or increase volume.
7. Press ⏻ to turn on the PWR05. A voice will say "voice on". To turn off the device, press this button for several seconds, then a voice will say "power off" shortly before the device will go out. NOTE: If the device is not sufficiently charged upon turning it on, the control panel will blink shortly, and a voice will say "power off" before turning off again. In this case charge your device or use it via the included power supply unit.
8. DC Input

9. Charging status button
Press this button to check the load status.
10. Status LEDs
While charging, the status LEDs will blink one after the other. As soon as the device is fully charged, all LEDs will be permanently lit.
11. USB port.
Connect an external USB device (5V,2A) to this port in order to charge your device.
NOTE: this USB port is intended for charging only. In order to charge an external device, the device has to be turned on.
12. Aux Input.
It is possible to connect an external playback device (e.g. CD player) via 3.5mm jack to the AUX input, if the PWR05 is already turned on while connecting an external playback device, a voice will say "audio mode on".
NOTE: In AUX mode, it is not possible to link two PWR05.

⚠ Warning: Make sure speaker is off and all LEVEL controls are down (counterclockwise) before every use.

Connections:

1. For this unit you can connect a mixer, microphone or CD player directly into your PWR05, to connect a device use 3.5mm Jack connector to connect to the AUX (12) input.
2. Turn on your mixer/microphones or other signal source, then turn on your unit, the Bluetooth indicator (4) will be lit, and will have Voice prompts, now you can adjust volume controls to a reasonable level.

Technical specifications

- 3-way system with active filter
- woofer : 6" paper cone
- midrange : 2 x 3" paper cone
- tweeter : 1" silk cone
- bass reflex
- amplifier power RMS : class D, 75 W
- amplifier power max : class D, 150 W
- frequency range : 60 Hz-20 kHz
- aux-input : 3.5 mm jack
- sources :
 - stereo Bluetooth/TWS
 - USB (charging) (Type A), 5V/2A
- wireless : Bluetooth 4.2
- battery with LED-indication : 6600 mA (10 hours)
- weight/piece : 4.4 kg
- casing : ABS-plastic
- colour : black
- measurements (hwxwd) : 430 x 180 x 180 mm
- accessories : carry strap

Warranty conditions

2 year warranty from the date of manufacture. The warranty is limited to the repair or replacement of the defective material insofar as this defect is a result of normal use and the device has not been damaged. Artsound is not responsible for any other costs that ensue as a result of the defect (e.g. transport). For details, please consult our general terms and conditions of sale.